

Headset Installation

Schuberth Flip Front Helmet



1. Remove neck roll by releasing the snaps on either side and pulling the reflective area forward until it releases.



5. Carefully tuck the long speaker wire between shell and EPS foam around to left the side of helmet.



2. Unhook the velcro holding the liner at the ear pockets and remove the cotton gauze inside (if equipped).



6. Carefully insert a screwdriver between the EPS foam and the molded plastic at the top of the cheek pad to loosen a small gap about 1/8" x 1/3" to accept the boom as shown in 7 below.



3. Remove (2) T-8 Torx screws holding the left cheek pad (only) in place.



7. Insert the boom into the gap, making sure the wire does not interfere with the flip-up visor mechanism.



4. Install speaker with the long wire into the right ear pocket horizontally with the wiring coming out of the back.



8. Install the short wire speaker into cheek pad in the same manner as the first.

- Attach the red mic connector to headset speaker loom
- Tuck excess wire behind the cheek pad (careful not to pinch wires or get in the way of the flip-up visor mechanism)



(Note: the helmet has a round recess molded into the EPS foam. This is the incorrect shape and is not positioned over the ear canal. This may require dimpling in the ear pocket in front and at the bottom of this round recess so the speaker fits into the recessed area more comfortably.)



9. Reinstall the cheek pad and neck roll and test the headset.

Note: With all headset installations, the rider's head fits his/her helmet as only it will. He or she must make all final adjustments to the microphone and speaker alignments.