

# Garmin Zumo 450 Connection Options

## To interface Garmin Zumo 450 for GPS and Music

(Super Pro Avi, Active-PLUS, Easi-PLUS, Pro-7-Sport, Active-7-Smart, Easi-7-Advance)

### Utilizing Interface #1314

Enables GPS and Music connection.

Part #1314 provides stereophonic binaural response

1. Insert 3.5mm stereo plug into the 3.5mm audio out socket on the Zumo's cradle.



Interface #1314 is designed to be used with all Autocom Systems.  
Interface to Systems as follows:

**Super Pro AVi** — Insert 3.5mm 3-Pole stereo plug into Socket **AUX2**.

**Active-PLUS** — Insert 3.5mm 3-Pole stereo plug into Socket **AUX2**.

**Easi-PLUS** — Insert 3.5mm 3-Pole stereo plug into Socket **AUX2**.

**Pro-7-Sport** — Insert 3.5mm 3-Pole stereo plug into Socket **MUSIC**.

**Active-7-Smart** — Insert 3.5mm 3-Pole stereo plug into Socket **MUSIC**.

**Easi-7-Advance** — Insert 3.5mm 3-Pole stereo plug into Socket **MUSIC**.

#### TIPS:

- The Audio Out Socket is located on the side of the Zumo's cradle underneath a protective rubber cover.

**If using a Garmin Zumo 550 you can use Part #1314 for GPS and Music.**

**If you want GPS, Music and to Bluetooth your cell phone, please refer to the Zumo550 options online in the support section.**



Please contact TopGear Accessories with any questions you may have online at [www.autocomamerica.com](http://www.autocomamerica.com) or 888-851-4327.